



Rim[®]

NÁVOD K POUŽITÍ
BEDIENUNGSANLEITUNG
OPERATING INSTRUCTIONS
MODE D'EMPLOI
INSTRUKCJA UŻYTKOWANIA
HASZNÁLATI ÚTMUTATÓ




FLEXi FX 1103
FLEXi FX 1104
FLEXi FX 1113
FLEXi FX 1114
VICTORY VI 1401
VICTORY VI 1411
EASY PRO EP 1204
EASY PRO EP 1204L
FOCUS FO 642C
ANATOM AT 985A
SYNCHRO ST1


1




2







3




4










FLEXi FX 1103
FLEXi FX 1104
FLEXi FX 1113
FLEXi FX 1114
FOCUS FO 642C
ANATOM AT 985A




FLEXi FX 1103
FLEXi FX 1113




FLEXi FX 1104
FLEXi FX 1114
VICTORY VI 1401
VICTORY VI 1411
EASY PRO EP 1204
EASY PRO EP 1204L
FOCUS FO 642C
ANATOM AT 985A









FLEXi FX 1103
FLEXi FX 1104
VICTORI VI 1401
VICTORY VI 1411
EASY PRO EP 1204
EASY PRO EP 1204L





FLEXi FX 1113
FLEXi FX 1114






ANATOM AT 985A






STOP!
STOP!






FLEXi FX 1103
FLEXi FX 1104
FLEXi FX 1113
FLEXi FX 1114
VICTORY VI 1401
VICTORY VI 1411




FOCUS FO 642C
ANATOM AT 985A

FLEXi FX 1103
FLEXi FX 1113

086 3F




088 4F





FLEXI FX 1104, FLEXI FX 1114
VICTORY VI 1401, VICTORY VI 1411
EASY PRO EP 1204, EASY PRO EP 1204L
FOCUS FO 642C




082 1F



083A 3F




084 4F






ANATOM AT 985A

082 1F



083A 3F



Rim[®]

RIM CZ s.r.o.

Dr. E. Beneše 1015

765 02 Otrokovice

CZECH REPUBLIC

Tel.: +420 577 112 641, -640

Fax: +420 577 101 015

E-mail: info@rim.cz

www.rim.cz

